

Fold-Down Hinged Window Grill Kit

Installation
Instructions

1. Mount and fasten the vertical side angles with the 1-1/4" screws, insuring both sides are plumb.
2. Install the bottom window L angle (with screw holes facing to the front) flush with the bottom of the side angles, using 1-14" screws.
3. Hold the top window L angle (slotted holes facing down) in position similar to the bottom angle. Outline the slotted hole dimensions onto the lumber. Notch out the holes to a depth of 1/2" and a width equal to or slightly greater than the outline.
4. Fasten the top L angle into place using 1-1/4" screws.
5. Install the 4" hinges onto the pre-assembled grill section matching hinge holes to the pre drilled holes in grill channel - use the 3/4" screws packaged with each hinge.
6. There must be 1/2" space between the bottom of the assembled grill section and the top of the bottom window L angle.
7. Position assembled window grill section, inserting the 2 spring loaded rods into the slotted holes and centered between the vertical side angles.
8. Making sure the 1/2" space is accurate, locate and mark the holes for mounting the bottom half of the hinges to the bottom window L angle.
9. Drill 3/6" diameter holes as marked, through the "metal thickness only" of the bottom window L angle and fasten the hinges using the 1-1/2" wood screws.
10. To open the window grill, simply pull down on the 2 spring loaded rods.

