

When splicing wire, gritted crimp sleeves are used to maintain the full strength of the wire. At end posts and inline tightener brackets, use two sleeves.

- Place sleeve into the slot in crimp tool marked for the gauge of wire you are using. Compress into a cylindrical shape. Do not split sleeve into an '8' shape.
- When using more than one sleeve per join, be sure to leave $\frac{1}{4}$ " between to allow proper expansion.
- For best results, sleeves should be kept dry prior to using.



Incorrect sleeve placement



Correct sleeve placement

