

HELPFUL TIPS ON MAKING ROUND PENDS

V2 0

- All posts set imconcrete
- 8' post spacing
- 3 rail 1 roll / 4 rail 1.5 rolls
- Lean posts 1" away from direction of pull
- Diameter X number of rails = total # of rolls
- Diagonal braces needed on either side of the gate
- Please reference RAMM Flex Fence® instructions for the diagonal bracing

