

INSTALLATION GUIDE FOR

# Mud Management by RAMM



## STEP 1



Expand panels to relax for installation. Prepare & compact subgrade to repair pre-existing ruts & support drainage.

## STEP 2



Roll out & install a water permeable barrier such as a landscape under layment.

## STEP 3



Connect & secure panels with stakes. Secure & protect your edges with a structural border. (example: pressure treated lumber)

## STEP 4



Infill Mud Management cells with crushed gravel.

## STEP 5



Overfill, water, & compact area with topsoil or stone of your choice.