


**Note: This quality tool has been pre-adjusted for you at the factory. Adjustments may be needed after extensive use.**

Check a crimped sleeve, as shown, with the gauge provided. If pressed portion won't go into gauge, adjust tool as outlined below.



With handles open, loosen locking screw with Allen wrench one or two turns. Turn adjustment screw clockwise about 1/4 turn. Tighten lock screw then make a press check with gauge. Repeat as needed until gauge easily passes over pressed sleeve.

Clean and oil tool occasionally. Except for some spring at final closing, "empty" tool should work freely.