



STEP 1

Install the 2"x4" pressure treated board at the bottom of the wall and flush with both the inside door post and outside wall post, using 3 1/2" spiral nails or wood screws. (Nails or screws are not supplied). Then install the remaining 2"x6" boards ensuring that they do not exceed the required height of 47 1/2". Do not completely secure the final board until you complete installing grommets in grill channels.

STEP 2

Install the rubber grommets for both the bottom grill channel and the corresponding top grill channel.
 NOTE: Use a soft face mallet or your fingers to install the rubber grommets into place.

STEP 3

Draw a horizontal line across the top wall board at a height of 46 1/2" from the floor. Then place the first grill channel 3/4" from the edge of the door opening side of the door post and align the bottom with the 46 1/2" line on the top wall board (use screws supplied to hold in place). Butt the next grill section to the first. Trim any access channel so it ends half way on the outside corner post. Now you can secure the top wall board in place.

Tack securely in place the 2"x6" lower header board at a height of 34 1/4" above the top of the bottom grill channel.

Place the top grill channel on top of the bottom grill channel with the open end facing up. Insert the grill bars through the top grill channel into the bottom grill channel. When all the grill bars are in place for that section, line up the top grill channel with the lower header and slide the top grill channel up and secure to the lower header. You may be required to pull out the bottom of the lower header board to be able to slide the top grill channel up into place. You may require assistance with this step. Do one section at a time.

