


# 90° Premium Track Trolley Brackets Assembly

Step 1 – Measuring 10” from the outside edge of the door, drill two 3/4” diameter holes approximately 3” deep.




Step 2 – Clean out the holes before proceeding.

Step 3 – Insert the 1/2” bolt through the hole in the trolley.

Step 4 – Thread the 1/2” nut all the way up on the bolt.


**DO NOT TIGHTEN.**



Step 5 – Slide a large and a small flange piece around the 1/2” bolt into the slots. Overlap the large flange piece on top of the small flange piece.

Step 6 – Screw on the flange nut.

**DO NOT TIGHTEN.** Final adjustments will be made after the door is hung.



Step 7 – Align the trolley assembly over the top of the door with the 1/2” bolt going into the drilled hole.

Step 8 – Adjust the flange pieces to fit around the door.

\*NOTE: The large flange piece will be on the outside face of the door and the small flange piece faces into the stall.

Step 9 – Drill a 5/16” hole completely through the door at the top two hole locations in the large flange piece.

Step 10 – Insert carriage bolts from the stall side of the doorthrough drilled holes in the door.

Step 11 – Attach nuts and tighten.

Step 12 – Fasten a clip screw through the bottom hole into the channel.

Step 13 – Hang the door and make any adjustments with the 1/2” nut and flange nut.

